

Live-View Remote RM-LVR2 Compatibility Chart

FUNCTION		Model														
		FDR-X3000	HDR-AS300	HDR-AS50	FDR-X1000V	HDR-AS200V	HDR-AZ1	HDR-AS20	HDR-AS100V	HDR-AS30V	HDR-AS15	ILCE-QX1	DSC-QX30	DSC-QX100	DSC-QX10	
Compatibility		○	○	○	○	○	○	○	○	○	○*1	○	○	○	○	
Connection	Connection	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
Shooting Mode	Movie	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Photo	○	○	○	○	○	○	○	○	○	-	○	○	○	○	
	Interval Photo Recording	○	○	○	○	○	○	○	○	○	○	-	-	-	-	
	Loop Recording	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	sound recording mode	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Recording Start/Stop	Movie recording Start/Stop	○	○	○	○	○	○	○	○	○	○	○	○	○	○	
	Photo shooting	○	○	○	○	○	○	○	○	○	-	○	○	○	○	
	Interval photo recording Start/Stop	○	○	○	○	○	○	○	○	○	○	-	-	-	-	
	Loop recording Start/Stop	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	recording sound Start/Stop	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Camera Settings	SteadyShot Setting	-	-	○	○	○	○	○	○	○	○	-	-	-	-	
	Angle Setting	-	-	-	○	○	-	-	-	○	○	-	-	-	-	
	Zooming	○	○	○	-	-	-	-	-	-	-	○*5	○	○	○	
	Automatic exposure mode setting	-	-	-	-	-	-	-	-	-	-	○	○	○	○	
	Flip setting	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	scene	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Color setting	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Movie record format	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Drive Mode setting	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Continuous shooting interval	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Self Timer	○	○	○	○	○	○	-	-	-	-	○	○	○*6	○*6	
	Time lapse	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Loop recording time	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	White Balance	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	AE shift	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	Audio recording setting	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	Wind noise reduction	○	○	○	○	○	-	-	-	-	-	-	-	-	-	
	Image Quality Settings	PS	○	○	○	○	○	○	○	○	○	○	-	○	-	-
		HQ	○	○	○	○	○	○	○	○	○	○	-	○	-	-
		STD	○	○	○	○	○	○	○	○	○	○	-	-	-	-
		VGA	-	-	-	-	-	○	○	○	○	○	-	-	-	-
		SLOW	-	-	-	-	-	-	○*3	-	○*3	○	-	-	-	-
		SSLOW	-	-	-	-	-	○	○*3	○	○*3	○	-	-	-	-
		HS120/HS100	○	○	○	○	○	○	-	○	-	-	-	-	-	-
		HS240/HS200	○	○	-	○	○	-	-	○	-	-	-	-	-	-
		HD 60p 50M/HD 50p 50M	○	○	○	○	○	○	-	○	-	-	-	-	-	-
		HD 30p 50M/HD 25p 50M	○	○	○	○	○	○	-	○	-	-	-	-	-	-
	Image Quality Settings	HD 24p 50M	○*3	○*3	○*3	○*3	○*3	○*3	-	○*3	-	-	-	-	-	-
		HD 120p 100M/HD 100p 100M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		HD 120p 60M/HD 100p 60M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		HD 240p 100M/HD 200p 100M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		HD 240p 60M/HD 200p 60M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		4K 30p 100M/4K 25p 100M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		4K 30p 60M/4K 25p 60M	○	-	-	○	-	-	-	-	-	-	-	-	-	-
		4K 24p 100M	○*3	-	-	○*3	-	-	-	-	-	-	-	-	-	-
4K 24p 60M		○*3	-	-	○*3	-	-	-	-	-	-	-	-	-	-	
Other Functions		Live-View Display	○	○	○	○	○	○	○	○	○	○	○	○	○	○
	Multi camera control	○	○	○	○	○	○	○	○	○*1	-	○	○	-	-	
	Memory card warning indicator	○	○	○	○	○	○	○	○	○*1	-	○	○	○	○	
	Automatic camera date setting	-	-	-	-	-	○	-	-	-	-	○	○	○	○	
	Battery level indicator of the camera	○	○	○	○	○	○	-	-	-	-	○	○	-	-	
	Remaining photos indicator	○	○	○	○	○	○	-	-	-	-	○	○	○	○	
	Remaining recording time indicator	○	○	○	○	○	○	-	-	-	-	○	○	-	-	
	Recorded time indicator	○	○	○	○	○	○	-	-	-	-	○	○	-	-	
	Interval photo number indicator	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Time code/user bit setting	○	-	-	○	○	○	-	-	-	-	-	-	-	-	
	IR-remote controller setting	○	-	-	○	○	○	-	-	-	-	-	-	-	-	
	Switching NTSC/PAL	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Auto power off setting	○	○	○	○	○	○	-	-	-	-	-	-	-	-	
	Beep setting	○	○	○	○	○	○	-	-	-	-	○	○	○	○	
	Memory card format	○	○	○	○	○	○	-	-	-	-	○	○	○	○	
	Playback	○	○	○	○	○	○	-	-	-	-	○	○	-	-	
	Delete	○	○	○	○	○	○	-	-	-	-	○	○	-	-	
Records GPS log	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Displays the software version of the camera		○	○	○	○	○	○	○	-	-	-	○	○	-	-	

*1 It is supported by updating the camera system software Ver.3.00 or later.

*3 Applicable only when in NTSC mode, not in PAL mode.

*5 Can be used with auto-power zoom(electric zoom) Lens attached.

*6 This setting is turned off automatically after taking a photo.

- Compatibility is not guaranteed with products not listed here.